AIR TO WATER HEAT PUMP



English

INSTALLATION MANUAL

OUTDOOR UNIT (3 phase type)

For authorized service personnel only.

Français

MANUEL D'INSTALLATION

UNITÉ EXTÉRIEUR (Type 3 phases)

Pour le personnel de service agrée uniquement.

PART No. 9380545255

INSTALLATION MANUAL
OUTDOOR UNIT
PART No. 9380545255

[Original instructions]
English

Contents

1. SAFETY PRECAUTIONS 1

2. ABOUT THE UNIT 2
- 2.1. Precautions for using R410A refrigerant 2
- 2.2. Special tools for R410A 2
- 2.3. Accessories 2

3. INSTALLATION WORK 2
- 3.1. Selecting an installation location 2
- 3.2. Drain installation 3
- 3.3. Installation dimensions 3
- 3.4. Transporting the unit 4
- 3.5. Installing the unit 4

4. PIPE SELECTION 5
- 4.1. Selecting the pipe material 5
- 4.2. Protection of pipes 5
- 4.3. Refrigerant pipe size and allowable piping length 5

5. PIPE INSTALLATION-1 5
- 5.1. Opening a knock out hole 5
- 5.2. Brazing 5
- 5.3. Flare connection 6
- 5.4. Pipe connection 6
- 5.5. Connection System 7
- 5.6. Sealing test 7
- 5.7. Vacuum process 7
- 5.8. Additional charging 7

6. ELECTRICAL WIRING 8
- 6.1. Selecting circuit breaker and wiring 8
- 6.2. Notes for electrical wiring 8
- 6.3. Knock out holes for wiring 9
- 6.4. Wiring method 9

7. PIPE INSTALLATION-2 10
- 7.1. Installing insulation 10
- 7.2. Filling with putty 10

8. HOW TO OPERATE FIELD SETTING BUTTONS 10
- 8.1. Display and buttons position 10
- 8.2. Description of display and button 10

9. FIELD SETTING 10
- 9.1. Function settings 10

10. EXTERNAL INPUT AND OUTPUT 12
- 10.1. External input 12
- 10.2. External output 13

11. TEST RUN 13

12.ERROR CODES 13
- 12.1. Error display mode 13
- 12.2. Error code check table 14

13. PUMP DOWN 14
- 13.1. Preparation for pump down 14
- 13.2. Pump down procedure 14

1. SAFETY PRECAUTIONS

Be sure to read this manual carefully before installation.
The warnings and precautions indicated in this manual contain important information pertaining to your safety. Be sure to observe them.
Hand this manual, together with the operating manual, to the customer. Request the customer to keep them on hand for future use, such as for relocating or repairing the unit.

⚠ WARNING	Indicates a potentially or imminently hazardous situation which, if not avoided, could result in death or serious injury.
Installation of this product must be done by experienced service technicians or professional installers only in accordance with this manual. Installation by nonprofessional or improper installation of the product may cause serious accidents such as injury, water leakage, electric shock, or fire. If the product is installed in disregard of the instructions in this manual, it will void the manufacturer's warranty.	

To avoid getting an electric shock, never touch the electrical components soon after the power supply has been turned off. After turning off the power, always wait 10 minutes or more before you touch the electrical components.
Do not turn on the power until all work has been completed. Turning on the power before the work is completed can cause serious accidents such as electric shock or fire.
If refrigerant leaks while work is being carried out, ventilate the area. If the refrigerant comes in contact with a flame, it produces a toxic gas.
Installation must be performed in accordance with regulations, codes, or standards for electrical wiring and equipment in each country, region, or the installation place.
Do not use this equipment with air or any other unspecified refrigerant in the refrigerant lines. Excess pressure can cause a rupture.
If there is a refrigerant leak, make sure that it does not exceed the concentration limit. If a refrigerant leak exceeds the concentration limit, it can lead to accidents such as oxygen starvation.
During installation, make sure that the refrigerant pipe is attached firmly before you run the compressor. Do not operate the compressor under the condition of refrigerant piping not attached properly with 3-way valve open. This may cause abnormal pressure in the refrigeration cycle that leads to rupture and even injury.
When installing and relocating the air conditioner, do not mix gases other than the specified refrigerant (R410A) to enter the refrigerant cycle. If air or other gas enters the refrigerant cycle, the pressure inside the cycle will rise to an abnormally high value and cause rupture, injury, etc.
To connect the indoor unit and outdoor unit, use air conditioner piping and cables available locally as standard parts. This manual describes proper connections using such installation set.
Do not modify power cable, use extension cable or branch wiring. Improper use may cause electric shock or fire by poor connection, insufficient insulation or over current.
Do not purge the air with refrigerants but use a vacuum pump to vacuum the installation.
There is no extra refrigerant in the outdoor unit for air purging.
Use a vacuum pump for R410A exclusively.
Using the same vacuum pump for different refrigerants may damage the vacuum pump or the unit.
Use a clean gauge manifold and charging hose for R410A exclusively.
During the pump-down operation, make sure that the compressor is turned off before you remove the refrigerant piping. Do not remove the connection pipe while the compressor is in operation with 3-way valve open. This may cause abnormal pressure in the refrigeration cycle that leads to rupture and even injury.
This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
To avoid danger of suffocation, keep the plastic bag or thin film used as the packaging material away from young children.

⚠ CAUTION	Indicates a potentially hazardous situation that may result in minor or moderate injury or damage to property.
For the air conditioner to work appropriately, install it as written in this manual.	
This product must be installed by qualified personnel with a capacity certification of handling refrigerant fluids. Refer to regulation and laws in use on installation place.	
Install the product by following local codes and regulations in force at the place of installation, and the instructions provided by the manufacturer.	
This product is part of a set constituting an air conditioner. The product must not be installed alone or be installed with a device not authorized by the manufacturer.	
Always use a separate power supply line protected by a circuit breaker operating on all wires with a distance between contact of 3 mm for this product.	
To protect the persons, earth (ground) the product correctly, and use the power cable combined with an Earth Leakage Circuit Breaker (ELCB).	
This product is not explosion proof, and therefore should not be installed in explosive atmosphere.	
Do not touch the fins of the heat exchanger. Touching the heat exchanger fins could result in damage to the fins or personal injury such as skin rupture.	
This product contains no user-serviceable parts. Always consult experienced service technicians for repairing.	
When moving or relocating the air conditioner, consult experienced service technicians for disconnection and reinstallation of the product.	
Do not place any other electrical products or household belongings under the product. Condensation dripping from the product might get them wet, and may cause damage or malfunction to the property.	
• This product is conformed to IEC/EN61000-3-2. • This product is designed for professional use. • On the power supply connection, obtain the connection permission of the distribution network operator. • Be sure to use a dedicated power circuit. Never use a power supply shared by another appliance.	

2. ABOUT THE UNIT

2.1. Precautions for using R410A refrigerant

⚠ WARNING
Do not touch refrigerant that has leaked from the refrigerant pipe connections or other areas. Touching the refrigerant directly can cause frostbite.
If a refrigerant leak occurs during operation, immediately vacate the premises and thoroughly ventilate the area. If the refrigerant comes in contact with a flame, it produces a toxic gas.
The basic installation work procedures are the same as conventional refrigerant models. However, pay careful attention to the following points:
• Since the working pressure is 1.6 times higher than that of conventional refrigerant (R22) models, some of the piping and installation and service tools are special. (See the table below.) Especially, when replacing a conventional refrigerant (R22) model with a new refrigerant R410A model, always replace the conventional piping and flare nuts with the R410A piping and flare nuts. • Models that use refrigerant R410A have a different charging port thread diameter to prevent erroneous charging with conventional refrigerant (R22) and for safety. Therefore, check beforehand. [The charging port thread diameter for R410A is 1/2-20 UNF.] • Be careful that foreign matter (oil, water, etc.) does not enter the piping than with refrigerant models. Also, when storing the piping, securely seal the openings by pinching, taping, etc. • When charging the refrigerant, take into account the slight change in the composition of the gas and liquid phases. And always charge from the liquid phase where refrigerant composition is stable.

2.2. Special tools for R410A

⚠ WARNING
To install a unit that uses R410A refrigerant, use dedicated tools and piping materials that have been manufactured specifically for R410A use. Because the pressure of R410A refrigerant is approximately 1.6 times higher than R22, failure to use dedicated piping material or improper installation can cause rupture or injury. Furthermore, it can cause serious accidents such as water leakage, electric shock, or fire.

Tool name	Contents of change
Gauge manifold	Pressure is high and cannot be measured with a conventional gauge. To prevent erroneous mixing of other refrigerants, the diameter of each port has been changed. It is recommended the gauge with seals –0.1 to 5.3 MPa (-1 to 53 bar) for high pressure. –0.1 to 3.8 MPa (-1 to 38 bar) for low pressure.
Charge hose	To increase pressure resistance, the hose material and base size were changed.
Vacuum pump	A conventional vacuum pump can be used by installing a vacuum pump adapter. Be sure that the pump oil does not back-flow into the system. Use one capable for vacuum suction of –100.7 kPa (5 Torr, –755 mmHg).
Gas leakage detector	Special gas leakage detector for HFC refrigerant R410A.

2.3. Accessories

⚠ WARNING
For installation purposes, be sure to use the parts supplied by the manufacturer or other prescribed parts. The use of non-prescribed parts can cause serious accidents such as the unit falling, water leakage, electric shock, or fire.

- The following installation parts are supplied. Use them as required.
- Keep the Installation Manual in a safe place and do not discard any other accessories until the installation work has been completed.

Name and shape	Q'ty	Description
Installation manual	1	(This manual)
Drain cap	9	For outdoor unit drain piping work
Drain pipe	1	For outdoor unit drain piping work
Auxiliary pipe	1	For connecting gas pipe (L type)
Push mount cable tie	2	For binding connection cable
Grommet edging	2	For power supply cable and connection cable installation. Attach to the knockout hole.

3. INSTALLATION WORK

- Make sure to obtain the customer's approval for selecting and installing the outdoor unit.

3.1. Selecting an installation location

⚠ WARNING
Securely install the outdoor unit at a location that can withstand the weight of the unit. Otherwise, the outdoor unit may fall and cause injury.
Be sure to install the outdoor unit as prescribed, so that it can withstand earthquakes and typhoons or other strong winds. Improper installation can cause the unit to topple or fall, or cause other accidents.
Do not install the outdoor unit near the edge of a balcony. Otherwise, children may climb onto the outdoor unit and fall off of the balcony.

⚠ CAUTION
Do not install the outdoor unit in the following areas: • Area with high salt content, such as at the seaside. It will deteriorate metal parts, causing the parts to fail or the unit to leak water. • Area filled with mineral oil or containing a large amount of splashed oil or steam, such as a kitchen. It will deteriorate plastic parts, causing the parts to fail or the unit to leak water. • Area that generates substances that adversely affect the equipment, such as sulfuric gas, chlorine gas, acid, or alkali. It will cause the copper pipes and brazed joints to corrode, which can cause refrigerant leakage. • Area containing equipment that generates electromagnetic interference. It will cause the control system to malfunction, preventing the unit from operating normally. • Area that can cause combustible gas to leak, contains suspended carbon fibers or flammable dust, or volatile inflammables such as paint thinner or gasoline. If gas leaks and settles around the unit, it can cause a fire. • Area that has heat sources, vapors, or the risk of the leakage of flammable gas in the vicinity. • Area where small animals may live. It may cause failure, smoke or fire if small animals enter and touch internal electrical parts. • Area where animals may urinate on the unit or ammonia may be generated.
Do not tilt the outdoor unit more than 0.3 degrees.
Install the outdoor unit in a well-ventilated location away from rain or direct sunlight.
If the outdoor unit must be installed in an area within easy reach of the general public, install as necessary a protective fence or the like to prevent their access.
Install the outdoor unit in a location that would not inconvenience your neighbors, as they could be affected by the airflow coming out from the outlet, noise, or vibration. If it must be installed in proximity to your neighbors, be sure to obtain their approval.
If the outdoor unit is installed in a cold region that is affected by snow accumulation, snow fall, or freezing, take appropriate measures to protect it from those elements. To ensure a stable operation, install inlet and outlet ducts.
Install the unit in an area that would not cause problems even if the drain water is discharged from the unit. Otherwise, provide drainage that would not affect people or objects.
Install the outdoor unit in a location that is away from exhaust or the vent ports that discharge vapor, soot, dust, or debris.
Install the indoor unit, outdoor unit, power supply cable, connection cable, and remote controller cable at least 1 m away from a television or radio receivers. The purpose of this is to prevent TV reception interference or radio noise. (Even if they are installed more than 1 m apart, you could still receive noise under some signal conditions.)
If children under 10 years old may approach the unit, take preventive measures so that they cannot reach the unit.
Keep the length of the piping of the indoor and outdoor units within the allowable range.
For maintenance purposes, do not bury the piping.

3.2. Drain installation

⚠ CAUTION
Perform drain work in accordance with this Manual, and ensure that the drain water is properly drained. If the drain work is not carried out correctly, water may drip down from the unit, wetting the furniture.
When the outdoor temperature is 0 °C or less, do not use the accessory drain pipe and drain cap. If the drain pipe and drain cap are used, the drain water in the pipe may freeze in extremely cold weather. (Reverse cycle model only)

- If you are installing the drain pipe and drain caps, please provide a working space under the base of the outdoor unit.
- As the drain water flows out of the outdoor unit during heating operation, install the drain pipe and connect it to a commercial 16 mm hose. (Reverse cycle model only)
- When installing the drain pipe, plug all the holes other than the drain pipe mounting hole in the bottom of the outdoor unit with putty so there is no water leakage. (Reverse cycle model only)





3.3. Installation dimensions

⚠ CAUTION	
Consider the transportation route, installation space, maintenance space, and access, and install the unit in a location with sufficient space for the refrigerant piping.	
Keep the space shown in the installation examples. If the installation is not performed accordingly, it could cause a short circuit and result in a lack of operating performance.	
Do not obstruct the air intake of the outdoor unit with piping, wiring, stand, etc.	
Installation methods not shown in the following examples are not recommended. Performance may drop significantly.	

3.3.1. Single outdoor unit installation

When the upward area is open (Unit : mm)

(1) Obstacles at rear only



(2) Obstacles at rear and sides



(3) Obstacles at front only



(4) Obstacles at front and rear



When an obstruction is present also in the upward area (Unit : mm)

(1) Obstacles at rear and above



(2) Obstacles at rear, sides, and above



3.3.2. Multiple outdoor unit installation

- Provide at least 100 mm of space between the outdoor units if multiple units are installed.
- When routing the piping from the side of an outdoor unit, provide space for the piping.
- No more than 3 units must be installed side by side.
  When 3 units or more are arranged in a line, provide the space as shown in the following example when an obstruction is present also in the upward area.

When the upward area is open (Unit : mm)

(1) Obstacles at rear only



(2) Obstacles at front only



(3) Obstacles at front and rear



When an obstruction is present also in the upward area (Unit : mm)

- Obstacles at rear and above only



3.3.3. Outdoor unit installation in multi row

* The following settings are not recommended in case of cooling by a low outside temperature. (Unit: mm)

(1) Single parallel unit arrangement



(2) Multiple parallel unit arrangement



3.4. Transporting the unit

⚠ WARNING

Do not touch the fins. Otherwise, personal injury could result.

⚠ CAUTION

When carrying the unit, hold the handles on the right and left sides and be careful.
If the outdoor unit is carried from the bottom, hands or fingers may be pinched.

Hoisting method

- When hoisting the outdoor unit, hook the rope on the outside of the foot as shown in the figure.
- Use sufficiently strong rope to bear the unit's weight.
- Place protective board or filler cloth at the place where the cabinet may come into contact with the rope to prevent damages. Without using them, the cabinet may be damaged or deformed.
- The center of gravity of the outdoor unit is shifted to the right. Be careful not to tilt to the heavy side causing it to fall.
- To prevent accidents caused by the unit swinging or falling down, do not apply any impact to the unit when it is hanging.
- When hoisting, do not hook the rope to the thermistor holder on the back of the outdoor unit.

Product mass (Kg)
138



Lifting by forklift

- When using the forklift to lift the unit, pass the forklift arms through the opening space of the wooden delivery pallet.
- Be careful not to damage.



Carrying by hand

- Carry slowly in the manner as shown on "Fig. B" holding the handles "Fig. A" in right and left sides. (Be careful not to touch with hands or objects.)
- Be sure to hold the handles on the sides of the unit. Otherwise, the suction grilles on the sides of the unit may be deformed.

Fig. A



Fig. B



3.5. Installing the unit

- Install 4 anchor bolts at the locations indicated with arrows in the figure.
- To reduce vibration, do not install the unit directly on the ground. Install it on a secure base (such as concrete blocks).
- The foundation shall support the legs of the unit and have a width of 80 mm or more.
- Depending on the installation conditions, the outdoor unit may spread its vibration during operation, which may cause noise and vibration. Therefore, attach damping materials (such as damping pads) to the outdoor unit during installation.
- Install the foundation, making sure that there is enough space for installing the connection pipes.
- Secure the unit to a solid block using foundation bolts. (Use 4 sets of commercially available M10 to M12 bolts, nuts, and washers.)
- The bolts should protrude 20 mm. (Refer to the figure.)
- If overturning prevention is required, purchase the necessary commercially available items.



- Do not install directly on the ground, this may result in equipment failure.
- The drain water is discharged from the bottom of the equipment. Construct a drain ditch around the base and discharge the drain water properly
- Provide ample space for ice buildup from condensate between the bottom of the unit and the flat surface on which it is mounted. Otherwise, there is risk that the drainage water will freeze between the device and the surface, disabling drainage.



⚠ CAUTION

If the unit is installed in a region that is exposed to high winds, freezing conditions, freezing rain, snow fall or heavy snow accumulation, take appropriate measures to protect it from those elements.
To ensure stable operation, the outdoor unit must be installed on a raised stand or rack, at or above the anticipated snow depth for the region.
The installation of snow hoods and drift prevention fencing is recommended when blowing and drifting snow is common to the region.



4. PIPE SELECTION

4.1. Selecting the pipe material

⚠ CAUTION

Do not use existing pipes.

Use pipes that have clean external and internal sides without any contamination which may cause trouble during use, such as sulfur, oxide, dust, cutting waste, oil, or water.

It is necessary to use seamless copper pipes.
Material: Phosphor deoxidized seamless copper pipes.
It is desirable that the amount of residual oil is less than 40 mg/10 m.

Do not use copper pipes that have a collapsed, deformed, or discolored portion (especially on the interior surface).
Otherwise, the expansion valve or capillary tube may become blocked with contaminants.

Improper pipe selection will degrade performance. As an air conditioner using R410A incurs pressure higher than when using conventional refrigerant, it is necessary to choose adequate materials.

- Thicknesses of copper pipes used with R410A are as shown in the table.
- Never use copper pipes thinner than those indicated in the table even if they are available on the market.

Table. A (Wall thickness and pipe material for each diameter)

Outside Diameter	mm	6.35	9.52	12.70	15.88	19.05
Wall Thickness *2	mm	0.8	0.8	0.8	1.0	1.2
Material		COPPER *1 JIS H3300 C1220T-O or equivalent				

Please select the pipe size in accordance with local rules.
*1: Allowable tensile stress ≥ 33 (N/mm^2)
*2: Endurance pressure of the pipes 4.2MPa

4.2. Protection of pipes

- Protect the pipes to prevent the entry of moisture and dust.
- Especially, pay attention when passing the pipes through a hole or connecting the end of a pipe to the outdoor unit.

Location	Working period	Protection method
Outdoor	1 month or more	Pinch pipes
	Less than 1 month	Pinch or tape pipes
Indoor	-	Pinch or tape pipes

4.3. Refrigerant pipe size and allowable piping length

⚠ CAUTION

Keep the piping length between the indoor unit and outdoor unit within the allowable tolerance.

Pipe diameter <Liquid/Gas> [mm (in.)]	9.52 (3/8) / 15.88 (5/8)
Max. piping length (L) [m]	30*
Min. piping length (L) [m]	5
Max. height difference <H1/H2> <Indoor unit to outdoor unit> [m]	15 / 25
View (Example)	

*: For the standard pipe diameter.

5. PIPE INSTALLATION-1

5.1. Opening a knock out hole

⚠ CAUTION

Be careful not to deform or scratch the panel while opening the knock out holes.

To protect the piping insulation after opening a knock out hole, remove any burrs from the edge of the hole. It is recommended to apply rust prevention paint to the edge of the hole.

- Pipes can be connected from 3 directions, front, lateral side and bottom. (Fig. A)
- When connecting at the bottom, remove the service panel and piping cover on the front of the outdoor unit, and open the knockout hole provided at the bottom corner of the piping outlet.

Fig. A





Front connection Lateral connection Bottom connection

- It can be installed as shown on “Fig. B” cutting out the 2 slits as indicated on “Fig. C”. (When cutting slits, use a steel saw.)

Fig. B



Fig. C



5.2. Brazing

⚠ CAUTION

If air or another type of refrigerant enters the refrigeration cycle, the internal pressure in the refrigeration cycle will become abnormally high and prevent the unit from exerting its full performance.

Apply nitrogen gas while brazing the pipes. If a pipe is brazed without applying nitrogen gas, an oxidation film will be created.
This can degrade performance or damage the parts in the unit (such as the compressor or valves).
Nitrogen gas pressure: 0.02 MPa
(= pressure felt sufficiently on the back of the hand)



⚠ CAUTION
For brazing material, use phosphor copper that does not require flux. Do not use flux to braze pipes. If the flux is the chlorine type, it will cause the pipes to corrode. Furthermore, if the flux contains fluoride, it will adversely affect the refrigerant pipe system such as by degrading the refrigerant. If fluoride is contained, quality of refrigerant deteriorates and affects the refrigerant piping system.

5.3. Flare connection

⚠ CAUTION
Do not use mineral oil on a flared part. Prevent mineral oil from getting into the system as this would reduce the lifetime of the units.
While welding the pipes, be sure to blow dry nitrogen gas through them.
The maximum lengths of this product are shown in the table. If the units are further apart than this, correct operation cannot be guaranteed.

5.3.1. Flaring

- Use special pipe cutter and flare tool exclusive for R410A.

(1) Cut the connection pipe to the necessary length with a pipe cutter.

(2) Hold the pipe downward so that the cuttings will not enter the pipe and remove any burrs.

(3) Insert the flare nut (always use the flare nut attached to the indoor and outdoor units respectively) onto the pipe and perform the flare processing with a flare tool. Leakage of refrigerant may result if other flare nuts are used.

(4) Protect the pipes by pinching them or with tape to prevent dust, dirt, or water from entering the pipes.



Pipe outside diameter [mm (in.)]	Dimension A [mm] Flare tool for R410A, clutch type	Dimension B $^{0}_{-0.4}$ [mm]
6.35 (1/4)	0 to 0.5	9.1
9.52 (3/8)		13.2
12.70 (1/2)		16.6
15.88 (5/8)		19.7
19.05 (3/4)		24.0

- When using conventional flare tools to flare R410A pipes, the dimension A should be approximately 0.5 mm more than indicated in the table (for flaring with R410A flare tools) to achieve the specified flaring. Use a thickness gauge to measure the dimension A.

Width across flats



Pipe outside diameter [mm (in.)]	Width across flats of Flare nut [mm]
6.35 (1/4)	17
9.52 (3/8)	22
12.70 (1/2)	26
15.88 (5/8)	29
19.05 (3/4)	36

5.4. Pipe connection

5.4.1. Bending pipes

⚠ CAUTION
To prevent breaking of the pipe, avoid sharp bends. Bend the pipe with a radius of curvature of 100 mm to 150 mm.
If the pipe is bent repeatedly at the same place, it will break.

- If pipes are shaped by hand, be careful not to collapse them.
- Do not bend the pipes at an angle of more than 90°.
- When pipes are repeatedly bent or stretched, the material will harden, making it difficult to bend or stretch them anymore.
- Do not bend or stretch the pipes more than three times.

5.4.2. Pipe connection

⚠ CAUTION
Be sure to install the pipe against the port on the indoor unit and the outdoor unit correctly. If the centering is improper, the flare nut cannot be tightened smoothly. If the flare nut is forced to turn, the threads will be damaged.
Do not remove the flare nut from the outdoor unit pipe until immediately before connecting the connection pipe.
After installing the piping, make sure that the connection pipes do not touch the compressor or outer panel. If the pipes touch the compressor or outer panel, they will vibrate and produce noise.

(1) Detach the caps and plugs from the pipes.

(2) Center the pipe against the port on the outdoor unit, and then turn the flare nut by hand.

(3) Tighten the flare nut of the connection pipe at the outdoor unit valve connector.



(4) After tightening the flare nut by hand, use a torque wrench to fully tighten it.

⚠ CAUTION
Hold the torque wrench at its grip, keeping it in a right angle with the pipe, in order to tighten the flare nut correctly.

- Outer panel may be distorted if fastened only with a wrench. Be sure to fix the elementary part with a spanner and fasten with a wrench (refer to below diagram).
- Do not apply force to the blank cap of the valve or hang a wrench, etc., on the cap. It may cause leakage of refrigerant.



Flare nut [mm (in.)]	Tightening torque [N·m (kgf·cm)]
6.35 (1/4) dia.	16 to 18 (160 to 180)
9.52 (3/8) dia.	32 to 42 (320 to 420)
12.70 (1/2) dia.	49 to 61 (490 to 610)
15.88 (5/8) dia.	63 to 75 (630 to 750)
19.05 (3/4) dia.	90 to 110 (900 to 1100)

*** Connection example**



5.4.3. Handling precautions for the valves

- Mounted part of Blank cap is sealed for protection.
- Fasten blank cap tightly after opening valves.

Table A

Blank cap [mm (in.)]	Tightening torque [N·m (kgf·cm)]
6.35 (1/4)	20 to 25 (200 to 250)
9.52 (3/8)	20 to 25 (200 to 250)
12.70 (1/2)	28 to 32 (280 to 320)
15.88 (5/8)	30 to 35 (300 to 350)
19.05 (3/4)	35 to 40 (350 to 400)

Operating the valves

- Use a hexagon wrench (size 3/16 in (4 mm)).

Opening:

(1) Insert the hexagon wrench into the valve shaft, and turn it counterclockwise.
(2) Stop turning when the valve shaft can no longer be turned. (Open position)

Closing:

(1) Insert the hexagon wrench into the valve shaft, and turn it clockwise.
(2) Stop turning when the valve shaft can no longer be turned. (Closed position)



5.5. Connection System

Fig. A Connection system



Fig. B



Table. A

Pipe	Spindle	Cap	Charging cap
Liquid valve	6.0 to 7.0 N·m (60 to 70 kgf·cm)	20.0 to 25.0 N·m (200 to 250 kgf·cm)	10.0 to 12.0 N·m (100 to 120 kgf·cm)
Gas valve	6.0 to 7.0 N·m (60 to 70 kgf·cm)	30.0 to 35.0 N·m (300 to 350 kgf·cm)	10.0 to 12.0 N·m (100 to 120 kgf·cm)

5.6. Sealing test

⚠ CAUTION

Use only nitrogen gas.
Never use refrigerant gas, oxygen, inflammable gas, or poisonous gas to pressurize the system.
(If oxygen is used, there is the danger of an explosion.)

Do not apply shock during sealing test.
It can rupture the pipes and cause serious injury.

Do not turn on the power unless all operations are complete.

⚠ CAUTION

Do not block the walls and the ceiling until the sealing test and the charging of the refrigerant gas have been completed.

After connecting the pipes, perform a sealing test.

(1) Recheck that the spindle of the 3-way valve are closed before performing a sealing test. (Refer to “5.5. Connecction System”, Fig. B)
(2) Pressurize nitrogen gas to 4.2 MPa to perform the sealing test.
(3) Add nitrogen gas to both the liquid pipes and the gas pipes.
(4) Check all flare connection areas and welded areas. Then, check that the pressure has not decreased.
(5) Compare the pressures after pressurizing and letting it stand for 24 hours, and check that the pressure has not decreased.

* When the outdoor temperature changes 5 °C, the test pressure changes 0.05 MPa. If the pressure has dropped, the pipe joints may be leaking.

(6) If a leakage is found, immediately repair it and perform the sealing test again.
* Decrease the pressure of nitrogen gas before blazing.
(7) After completing the sealing test, release the nitrogen gas from both valves. Release the nitrogen gas slowly.

5.7. Vacuum process

⚠ CAUTION

Do not turn on the power unless all operations are complete.

If the system is not evacuated sufficiently, its performance will drop.

Be sure to evacuate the refrigerant system using a vacuum pump.

The refrigerant pressure may sometimes not rise when a closed valve is opened after the system is evacuated using a vacuum pump. This is caused by the closure of the refrigerant system of the outdoor unit by the electronic expansion valve. This will not affect the operation of the unit.

Use a clean gauge manifold and charging hose that were designed specifically for use with R410A. Using the same vacuum equipment for different refrigerants may damage the vacuum pump or the unit.

Do not purge the air with refrigerants, but use a vacuum pump to evacuate the system.

If moisture might enter the piping, follow below.
(I.e., if doing work during the rainy season, if the actual work takes long enough that condensation may form on the inside of the pipes, if rain might enter the pipes during work, etc.)
- After operating the vacuum pump for two hours, pressurize to 0.05 MPa (i.e., vacuum breakdown) with nitrogen gas, then depressurize down to -100.7kPa (-755mmHg) for an hour using the vacuum pump (vacuum process).
- If the pressure does not reach -100.7kPa (-755mmHg) even after depressurizing for at least two hours, repeat the vacuum breakdown - vacuum process.

After vacuum process, maintain the vacuum for an hour and make sure the pressure does not rise by monitoring with a vacuum gauge.

Evacuation procedure

(1) Remove the caps of the gas pipe and liquid pipe and check that the valves are closed.
(2) Remove the charging cap.
(3) Connect a vacuum pump and a pressure gauge to a charging hose and connect it to the charging port.
(4) Activate the vacuum pump and vacuum the indoor unit and connection piping until the pressure gauge becomes -100.7kPa (-755mmHg).
Evacuate from both the gas pipe and the liquid pipe.
(5) Continue evacuating the system for 1 hour after the pressure gauge reads -100.7kPa (-755mmHg).
(6) Remove the charging hose and reinstall the charging cap.

5.8. Additional charging

⚠ CAUTION

Do not turn on the power unless all operations are complete.

After evacuating the system, add refrigerant.

Do not charge the system with a refrigerant other than R410A.

Always keep to the limit on the total amount of refrigerant. Exceeding the limit on the total amount of refrigerant will lead to malfunction during charging of refrigerant.

Do not reuse recovered refrigerant.

Use an electronic scale to measure the charging amount of refrigerant.
Adding more refrigerant than the specified amount will cause a malfunction.

Add refrigerant by charging the system with the refrigerant in the liquid state.

When charging the refrigerant, take into account the slight change in the composition of the gas and liquid phases, and always charge from the liquid phase side whose composition is stable. Adding refrigerant through the gas pipe will cause a malfunction.

⚠ CAUTION
Check if the steel cylinder has a siphon installed or not before filling. (There is an indication “with siphon for filling liquid” on the steel cylinder.) **Filling method for cylinder with siphon**    Set the cylinder vertical and fill with the liquid. (Liquid can be filled without turning bottom up with the siphon inside.) **Filling method for other cylinders**    Turn bottom up and fill with liquid. (Be careful to avoid turning over the cylinder.)
Be sure to use the special tools for R410A for pressure resistance and to avoid mixing of impure substances.
If the units are further apart than the maximum pipe length, correct operation cannot be guaranteed.
Make sure to back closing valve after refrigerant charging. Otherwise, the compressor may fail.
Minimize refrigerant release to the air. Excessive release is prohibited under the Freon Collection and Destruction Law.

5.8.1. If additional refrigerant is required

- When the piping is longer than chargeless piping length, additional charging is necessary.

1) Remove the charging cap from the liquid pipe.
2) Attach a charging hose to the refrigerant cylinder, and connect it to the charging port.
3) Add refrigerant by calculating the additional refrigerant volume in accordance with the table below.
4) Remove the charging hose and install the charging cap.
5) Remove the body caps (gas pipe, and liquid pipe), and open the valves.
6) Close the body caps.

* Tighten the body caps and charging caps to the torque values specified in the Table A.
To open and close the valves;
Use an M5 hexagon wrench for liquid pipes.
Use an M10 hexagon wrench for gas pipes.

Piping length (L1) *Chargeless [m]
15

Additional charging amount

L1* > Chargeless piping length

Refrigerant pipe size [mm (in.)]		Piping length				
Standard		~15 m	20 m	25 m	30 m	g/m
Liquid	9.52 (3/8)	None	250 g	500 g	750 g	50 g/m
Gas	15.88 (5/8)					

Refer to “4.3. Refrigerant pipe size and allowable piping length”.

6. ELECTRICAL WIRING

6.1. Selecting circuit breaker and wiring

- Decide the diameter of wire referring to below table “Breaker and wiring specifications” in accordance with local and national codes.

Breaker and wiring specifications

Breaker capacity [A]	Power supply cable	Transmission cable*	
	Conductor size [mm²]	Conductor size [mm²]	Max. length [m]
16	2.5 min.	1.5 min.	50

*: If the transmission wire is longer than 50m, use a bigger conductor size.

- Use confirmed cable with type 245 IEC 57.
- Perform all electrical work according to standard.
- Install a circuit breaker with a contact gap of at least 3 mm in all poles near the units. (Both indoor units and outdoor units)
- Install the circuit breaker near the units.

6.2. Notes for electrical wiring

⚠ WARNING
Wiring connections must be performed by a qualified person in accordance with specifications. The rated supply of this product is 50 Hz, 400 V of 3-phase, 4-wire. Use a voltage within the range of 342 to 456 V (50 Hz).
Make sure to perform earthing (grounding) work. Improper earthing (grounding) work can cause electric shocks.
Before connecting the cables, make sure the power supply is OFF.
Be sure to install an earth (ground) leakage breaker. Otherwise, it will cause electric shock or fire.
Select a breaker (Included with earth leakage circuit breaker) of appropriate capacity and install one at every power supply of an outdoor unit. Wrong selection of breakers or transition wiring will lead to electric shock and fire.
Do not connect AC power supply to the transmission line terminal board. Improper wiring can damage the entire system.
Install a breaker (Included with earth leakage circuit breaker) in accordance with the related laws and regulations.
Connect the connector cable securely to the terminal. Faulty installation can cause a fire.
Make sure to secure the insulation portion of the connector cable with the cable clamp. A damaged insulation can cause a short circuit.
Never install a power factor improvement condenser. Instead of improving the power factor, the condenser may overheat.
Before servicing the unit, turn the power supply switch OFF. Then, do not touch electric parts for 10 minutes due to the risk of electric shock.
Always use a separate power supply line protected by a circuit breaker operating on all cables with a distance between contact of 3 mm for this unit.
Do not modify power cable, use extension cable or branch wiring. Improper use may cause electric shock or fire by poor connection, insufficient insulation or over current.
Use ring terminals and tighten the terminal screws to the specified torques, otherwise, abnormal overheating may be produced and possibly cause serious damage inside the unit.
Securely install the electrical box cover on the unit. An improperly installed service panel can cause serious accidents such as electric shock or fire through exposure to dust or water.
If the supply cable is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

⚠ CAUTION
The primary power supply capacity is for the air conditioner itself, and does not include the concurrent use of other devices.
Connect the power cables in positive phase sequence. If there is a missing phase connection, the unit will not operate normally.
Do not use crossover power supply wiring for the outdoor unit.
If the electrical power is inadequate, contact your electric power company.
Install a breaker (Included with earth leakage circuit breaker) in a location that is not exposed to high temperatures. If the temperature surrounding the breaker is too high, the amperage at which the breaker cuts out may decrease.
Use a breaker (Included with earth leakage circuit breaker) that is capable of handling high frequencies. Because the outdoor unit is inverter controlled, a high-frequency earth leakage circuit breaker is necessary to prevent a malfunction of the breaker itself.
When the electrical switchboard is installed outdoors, place it under lock and key so that it is not easily accessible.
Never bundle the power supply cable and connection cable, remote control cable together. Separate these cable by 50 mm or more. Bundling these cables together will cause miss operation or breakdown.
Always keep to the maximum length of the connection cable. Exceeding the maximum length may lead to erroneous operation.
The static electricity that is charged to the human body can damage the control PC board when handling the control PC board for address setting, etc. Please keep caution to the following points. Provide the grounding of Indoor unit, Outdoor unit and Option equipment. Cut off the power supply (breaker). Touch the metal section (such as the unpainted control box section) of the indoor or outdoor unit for more than 10 seconds. Discharge the static electricity in your body. Never touch the component terminal or pattern on the PC board.

How to connect wiring to the terminal

Caution when wiring cable

- When stripping off the coating of a lead wire, always use a special tool such as a wire stripper. If there is no special tool available, carefully strip the coating with a knife etc.

(1) Use ring terminals with insulating sleeves as shown in the figure below to connect to the terminal block.
(2) Securely clamp the ring terminals to the wires using an appropriate tool so that the wires do not come loose.



(3) Use the specified wires, connect them securely, and fasten them so that there is no stress placed on the terminals.

(4) Use an appropriate screwdriver to tighten the terminal screws. Do not use a screwdriver that is too small, otherwise, the screw heads may be damaged and prevent the screws from being properly tightened.

(5) Do not tighten the terminal screws too much, otherwise, the screws may break.





(6) See the table below for the terminal screw tightening torques.

Tightening torque [N·m (kgf·cm)]	
M4 screw	1.2 to 1.8 (12 to 18)
M5 screw	2.0 to 3.0 (20 to 30)

6.3. Knock out holes for wiring

⚠ CAUTION
Be careful not to deform or scratch the panel while opening the knockout holes.
After opening the knockout holes, remove burr on the edges, and attach the one-touch bush (accessory), grommet or conduit etc. to prevent damaging the cables. It is recommended to apply rust proof paint on the edges to prevent rust.

Knockout holes are provided in front and lateral sides for wiring.



Length of the grommet edging



Knockout hole diameter (mm)	Dimension **L** (mm)
Ø 50	147
Ø 34.5	100
Ø 22.2	60

Mounting the grommet edging



6.4. Wiring method

6.4.1. Connection diagrams



6.4.2. Connection cable preparation

- Keep the earth wire longer than the other wires.



6.4.3. Wiring procedure

(1) Remove the service panel, the terminal cover and connect the wires to the terminal in accordance with the terminal nameplate. (Fig. A, Fig. B)

(2) Secure the cables using the cable clamps under the terminal blocks. (Fig. B)

- Connect the wires without applying excessive tension.

(3) Secure the cables using the cable ties at the base of the valves. (Fig. A)

Fig. A



Fig. B



(4) Be sure to install the terminal cover after the wiring is complete.

7. PIPE INSTALLATION-2

7.1. Installing insulation

- Use an insulation on the refrigerant pipes to prevent burn injury, condensation and dripping.

7.2. Filling with putty

⚠ WARNING

Fill the piping holes and wiring holes with putty (locally purchased) to avoid any gap (Fig A). If small animals such as insects enter the external unit, a short circuit may be caused near electrical components in the service panel.

If the outdoor unit is installed at a level that is higher than the indoor unit, the water that has condensed in the 3-way valve of the outdoor unit could travel to the indoor unit. Therefore, use putty in the space between the pipe and the insulation to prevent the entry of water to the indoor units.

Fig. A



8. HOW TO OPERATE FIELD SETTING BUTTONS

8.1. Display and buttons position

⚠ WARNING

Never touch electrical components such as the terminal blocks except the button on the display board. It may cause a serious accident such as electric shock.

⚠ CAUTION

Once refrigerant charging is completed, be sure to open the valve prior to performing the local settings. Otherwise, the compressor may fail.

Discharge any static electricity from your body before touching the push buttons. Never touch any terminal or pattern of any parts on the control board.

- Remove the front panel of the outdoor unit to access the print circuit board of the display unit.
- The positions of the buttons on the outdoor unit control board are shown in the figure below.
- Various settings can be adjusted by changing Push buttons on the board of the outdoor unit.



- The printed characters for the LED display are shown below.





8.2. Description of display and button

Display lamp		Function or operation method
(1) POWER / MODE	Green	Lights on while power on. Local setting in out-door unit or error code is displayed with blink.
(2) ERROR	Red	Blinks during abnormal air-conditioner operation.
(3) PUMP DOWN (L1)	Orange	Lights on during pump down operation.
(4) LOW NOISE MODE (L2, L3)	Orange	Lights on during “Low noise” function when local setting is activated. (Lighting pattern of L2 and L3 indicates low noise level) *See page 11.
(5) PEAK CUT (L4, L5, L6)	Orange	Lights on during “Peak cut” function when local setting is activated. (Lighting pattern of L4, L5 and L6 indicates peak cut level) *See page 11.

Button		Function or operation method
SW107	MODE/EXIT	To switch between “Local setting” and “Error code display”.
SW108	SELECT	To switch between the individual “Local settings” and the “Error code displays”.
SW109	ENTER	To fix the individual “Local settings” and the “Error code displays”.
SW112	EXIT	To return to “Operation status displays.”
SW110	PUMP DOWN	To start the pump down operation.

9. FIELD SETTING

⚠ CAUTION

Discharge the static electricity from your body before setting up the switches.
Never touch the terminals or the patterns on the parts that are mounted on the board.

9.1. Function settings

- Various functions can be set. Follow the setting methods described in 9.1.1. to 9.1.4. to set as per the requirement.
  Perform these settings after the indoor unit stops.

Table. Settings List

No	Setting Item		LED display								Factory setting	Content
			POWER/ MODE	ERROR	PUMP DOWN (L1)	LOW NOISE (L2)	LOW NOISE (L3)	PEAK CUT (L4)	PEAK CUT (L5)	PEAK CUT (L6)		
1	Low noise mode	Level 1	Blink (9 times)	○	○	○	●	○	○	●	◆	By using the “Low noise mode”, the limit of the noise level will be set to decrease the noise level. The mode comes in 2 levels which can be set accordingly. To turn on the mode, use the external input terminal (CN131). *By using this mode, the cooling/heating performance may decrease. *Depending on the operating condition, the noise level may not decrease even if the Low noise mode is on.
		Level 2	Blink (9 times)	○	○	○	●	○	●	○		
2	Peak cut mode	Level 1	Blink (9 times)	○	○	●	○	○	○	●	◆	The capacity limit can be selected when operating with the “Peak cut mode.” The operation selection can be done by external input terminal (CN132) The higher the level, the more the effect of energy saving, but the cooling/heating performance decreases.
		Level 2	Blink (9 times)	○	○	●	○	○	●	○		
		Level 3	Blink (9 times)	○	○	●	○	○	●	●		
		Level 4	Blink (9 times)	○	○	●	○	●	○	○		
3	Base heater control	Level 1	Blink (9 times)	○	○	●	●	○	○	●		This mode changes the operating time of the base heater. In order to control the base heater, connection to a separate base heater (locally purchased) is necessary. By changing the mode to Level 1, the base heater control mentioned in “10.3.2.” will be On at all times.
		Level 2	Blink (9 times)	○	○	●	●	○	●	○	◆	
4	Defrost determination control	Level 1	Blink (9 times)	○	●	○	○	○	○	●	◆	Setting this function enables quicker defrost determination.
		Level 2	Blink (9 times)	○	●	○	○	○	●	○		

Sign “○”: Lights off, “●”: Lights on

9.1.1. Setting for Low noise mode

(1) Switch to “Local setting mode” by pressing [MODE] button (SW107) for 3 seconds or more.

(2) Confirm (POWER / MODE) blinks 9 times, and press [ENTER] button (SW109).

POWER/ MODE	ERROR	PUMP DOWN (L1)	LOW NOISE (L2)	LOW NOISE (L3)	PEAK CUT (L4)	PEAK CUT (L5)	PEAK CUT (L6)
Blink (9 times)	○	○	○	○	○	○	○

Sign “○”: Lights off, “●”: Lights on, () : Number of blinking

(3) Press [SELECT] button (SW108), and adjust LED display as shown below. (Current setting is displayed)

	LOW NOISE (L2)	LOW NOISE (L3)
Low noise mode	○	Blink

Sign “○”: Lights off

(4) Press [ENTER] button (SW109).

	LOW NOISE (L2)	LOW NOISE (L3)
Low noise mode	○	●

Sign “○”: Lights off, “●”: Lights on

(5) Press [SELECT] button (SW108), and adjust LED lamp as shown in below figure.

		PEAK CUT (L4)	PEAK CUT (L5)	PEAK CUT (L6)
Level 1	(Low)	○	○	Blink
Level 2	(Lower)	○	Blink	○

Sign “○”: Lights off

The noise of Level 2 is lower than the one of Level 1.

(6) Press [ENTER] button (SW109) and fix it.

		PEAK CUT (L4)	PEAK CUT (L5)	PEAK CUT (L6)
Level 1	(Low)	○	○	●
Level 2	(Lower)	○	●	○

Sign “○”: Lights off, “●”: Lights on

(7) Return to “Operating status display (Normal operation)” by pressing [EXIT] button (SW112).

- In case of missing how many times [SELECT] and [ENTER] button are pressed, restart from the beginning of operation procedure after returning to “Operation status display (normal operation)” by pressing the [EXIT] button once.

9.1.2. Setting for peak cut mode

(1) Switch to “Local setting mode” by pressing [MODE] button (SW107) for 3 seconds or more.

(2) Confirm (POWER / MODE) blinks 9 times, and press [ENTER] button (SW109).

POWER/ MODE	ERROR	PUMP DOWN (L1)	LOW NOISE (L2)	LOW NOISE (L3)	PEAK CUT (L4)	PEAK CUT (L5)	PEAK CUT (L6)
Blink (9 times)	○	○	○	○	○	○	○

Sign “○”: Lights off, “●”: Lights on, () : Number of blinking

(3) Press [SELECT] button (SW108), and adjust LED lamp as shown below. (Current setting is displayed)

	LOW NOISE (L2)	LOW NOISE (L3)
Peak cut mode	Blink	○

Sign “○”: Lights off

(4) Press [ENTER] button (SW109).

	LOW NOISE (L2)	LOW NOISE (L3)
Peak cut mode	●	○

Sign “○”: Lights off, “●”: Lights on

(5) Press [SELECT] button (SW108), and adjust LED lamp as shown in below figure.

		PEAK CUT (L4)	PEAK CUT (L5)	PEAK CUT (L6)
Level 1	100% of rated input ratio	○	○	Blink
Level 2	75% of rated input ratio	○	Blink	○
Level 3	50% of rated input ratio	○	Blink	Blink
Level 4	0% of rated input ratio	Blink	○	○

Sign “○”: Lights off

(6) Press [ENTER] button (SW109) and fix it.

		PEAK CUT		
		(L4)	(L5)	(L6)
Level 1	100% of rated input ratio	○	○	●
Level 2	75% of rated input ratio	○	●	○
Level 3	50% of rated input ratio	○	●	●
Level 4	0% of rated input ratio	●	○	○

Sign "○": Lights off, "●": Lights on

(7) Return to "Operating status display (Normal operation)" by pressing [EXIT] button (SW112).

- When pressed number is lost during operation, restart from the beginning of operation procedure after returning to "Operation status display (normal operation)" by pressing the [EXIT] button once.

9.1.3. Setting for Base heater control

(1) Switch to "Local setting mode" by pressing [MODE] button (SW107) for 3 seconds or more.

(2) Confirm (POWER / MODE) blinks 9 times, and press [ENTER] button (SW109).

POWER/ MODE	ERROR	PUMP DOWN	LOW NOISE		PEAK CUT		
		(L1)	(L2)	(L3)	(L4)	(L5)	(L6)
Blink (9 times)	○	○	○	○	○	○	○

Sign "○": Lights off, "●": Lights on, () : Number of blinking

(3) Press [SELECT] button (SW108), and adjust LED display as shown below. (Current setting is displayed)

	LOW NOISE	
	(L2)	(L3)
Base heater control	Blink	Blink

Sign "○": Lights off

(4) Press [ENTER] button (SW109).

	LOW NOISE	
	(L2)	(L3)
Base heater control	●	●

Sign "○": Lights off, "●": Lights on

(5) Press [SELECT] button (SW108), and adjust LED lamp as shown in below figure.

		PEAK CUT		
		(L4)	(L5)	(L6)
Level 1	(On at all times)	○	○	Blink
Level 2	(Normal)	○	Blink	○

Sign "○": Lights off

The noise of Level 2 is lower than the one of Level 1.

(6) Press [ENTER] button (SW109) and fix it.

		PEAK CUT		
		(L4)	(L5)	(L6)
Level 1	(On at all times)	○	○	●
Level 2	(Normal)	○	●	○

Sign "○": Lights off, "●": Lights on

(7) Return to "Operating status display (Normal operation)" by pressing [EXIT] button (SW112).

- In case of missing how many times [SELECT] and [ENTER] button are pressed, restart from the beginning of operation procedure after returning to "Operation status display (normal operation)" by pressing the [EXIT] button once.

9.1.4. Setting for Defrost determination control

(1) Switch to "Local setting mode" by pressing [MODE] button (SW107) for 3 seconds or more.

(2) Confirm (POWER / MODE) blinks 9 times, and press [ENTER] button (SW109).

POWER/ MODE	ERROR	PUMP DOWN	LOW NOISE		PEAK CUT		
		(L1)	(L2)	(L3)	(L4)	(L5)	(L6)
Blink (9 times)	○	○	○	○	○	○	○

Sign "○": Lights off, "●": Lights on, () : Number of blinking

(3) Press [SELECT] button (SW108), and adjust LED lamp as shown below. (Current setting is displayed)

	PUMP DOWN	LOW NOISE	
	(L1)	(L2)	(L3)
Defrost determination control	Blink	○	○

Sign "○": Lights off

(4) Press [ENTER] button (SW109).

	PUMP DOWN	LOW NOISE	
	(L1)	(L2)	(L3)
Defrost determination control	●	○	○

Sign "○": Lights off, "●": Lights on

(5) Press [SELECT] button (SW108), and adjust LED lamp as shown in below figure.

		PEAK CUT		
		(L4)	(L5)	(L6)
Level 1	(Normal)	○	○	Blink
Level 2	(Quicker)	○	Blink	○

Sign "○": Lights off

(6) Press [ENTER] button (SW109) and fix it.

		PEAK CUT		
		(L4)	(L5)	(L6)
Level 1	(Normal)	○	○	●
Level 2	(Quicker)	○	●	○

Sign "○": Lights off, "●": Lights on

(7) Return to "Operating status display (Normal operation)" by pressing [EXIT] button (SW112).

- When pressed number is lost during operation, restart from the beginning of operation procedure after returning to "Operation status display (normal operation)" by pressing the [EXIT] button once.

10. EXTERNAL INPUT AND OUTPUT

Outdoor unit PC board



10.1. External input

10.1.1. Wiring of connector

ON/OFF of the "Low noise mode", and "Peak cut mode" functions can be enabled with an external field device.
When installing connection cable, specified part (UTY-XWZXZ3) must be used.
Refer to section 9.1. Table. Settings List, for the required function. The function must be set for the external input to work.

Input	Connector
Low noise mode	CN131
Peak cut mode	CN132

* Make the distance from the PC board to the connected unit within 10m (33ft).

• The switch can be used on the following condition: DC 12 V to 24 V, 1 mA to 15 mA.

Circuit diagram example



10.1.2. Low noise mode (CN131)

• This features reduces the operating sound of the outdoor unit from the normal sound. The air conditioner is set to the "Low noise mode" when closing the contact input of a commercial timer or ON/OFF switch to a connector on the outdoor control PC board.

* Performance may drop depending on the outside air temperature condition, etc.

* Set the "Low noise mode" level, refer to "9.1. Function settings".

Input Signal ···ON : Low noise mode
···OFF : Normal operation



10.1.3. Peak cut mode (CN132)

• Operation that suppressed the current value can be performed by means of the connected unit. The air conditioner is set to the Peak cut mode by applying the contact input of a commercial ON/OFF switch to a connector on the outdoor control PC board.

* Set the "Peak cut mode" level, refer to "9.1. Function settings".

Input Signal ···ON : Peak cut mode
···OFF : Normal operation



10.2. External output

10.2.1. Wiring of connector

When installing connection cable, specified part (UTY-XWZXZ3) must be used.

Output	Connector
Error status	CN136
Base heater control	CN137

* Make the distance from the PC board to the connected unit within 10m (33ft).

1) Power supply
• Voltage (Chart sign=Vcc) : DC 24V or less
2) Load
• Load : DC 500mA or less is recommended

10.2.2. Error status output (CN136)

Circuit diagram example



An air conditioner error status signal is produced when a malfunction occurs.



10.2.3. Base heater control output (CN137)

This is the output signal for the base heater. The output signal is on, when the outdoor temperature drops below 2°C, and signal is off when it rises to 5°C.



*: The allowable current is 1A or less.

11. TEST RUN

⚠ CAUTION
Always turn on the power 6 hours prior to the start of the operation in order to protect the compressor.
Before performing the test run, make sure that the 3-way valve is open.

• Perform test run described in installation manual of indoor unit.

12.ERROR CODES

You can determine the operating status by the lighting up and blinking of the LED lamp.





12.1. Error display mode

12.1.1. Display when an error occurs

POWER/ MODE	ERROR	LOW NOISE (L1)	LOW NOISE (L2)	PEAK CUT (L3)	PEAK CUT (L4)	PEAK CUT (L5)
●	Blink (Hi speed)	○	○	○	○	○

(1) Check that the "ERROR" LED blinks, and then "short-press" the [ENTER] switch once.

12.1.2. Display while an error code is blinking

POWER/ MODE	ERROR	LOW NOISE (L1)	LOW NOISE (L2)	PEAK CUT (L3)	PEAK CUT (L4)	PEAK CUT (L5)
Blinks (Twice)	Blinks	○	○	○	○	○

(2) The "POWER MODE" LED will blink twice and the "ERROR" LED will blink several times.

• The number of blinks of the "ERROR" LED varies according to the type of error. For details, refer to the "Error code check table".

12.2. Error code check table

Number of blinks (LED)	Error type
1	Serial forward transfer error
2	Discharge thermistor error
3	Pressure sensor error
4	Heat-exchange thermistor (outlet) error
5	Heat-exchange thermistor (intermediate) error
6	Expansion valve thermistor error
7	Outdoor temperature thermistor error
8	Compressor thermistor error
9	Heatsink thermistor (inverter) error
10	Heatsink thermistor (P.F.C.) error
11	Discharge temperature protection (permanent stoppage)
12	Compressor temperature protection (permanent stoppage)
13	Current trip (permanent stoppage)
14	Detection of compressor position error (permanent stoppage)
15	Compressor start up error (permanent stoppage)
16	Fan motor (1) error (permanent stoppage)
17	Fan motor (2) error (permanent stoppage)
18	Inverter error
19	P.F.C. error
20	Low pressure abnormal
21	Connection with indoor unit error
22	Indoor unit abnormality condition
23	Discharge (high pressure) pressure sensor error
24	Suction (low pressure) pressure sensor error

13. PUMP DOWN

⚠ WARNING

Never touch electrical components such as the terminal blocks except the button on the display board. It may cause a serious accident such as electric shock.

During the pump-down operation, make sure that the compressor is turned off before you remove the refrigerant piping.
Do not remove the connection pipe while the compressor is in operation with 2-way or 3-way valve open. This may cause abnormal pressure in the refrigeration cycle that leads to breakage and even injury.

⚠ CAUTION

Perform the pump down operation before disconnecting any refrigerant pipe or electric cable.

Collect refrigerant from the service port or the 3-way valve if pump down cannot be performed.

In case of a group control system installation, do not turn the power off until pump down is completed in all outdoor units.
(Group control system installation described in “SPECIAL INSTALLATION METHODS” in the installation manual of the indoor unit.)

- Operate [PUMP DOWN] button on the display board in the manner described below.



13.1. Preparation for pump down

- Confirm that the power is off, and then open the service panel.

13.2. Pump down procedure

(1) Check the 3-way valves (both the liquid side and gas side) are opened.

(2) Turn the power on.

POWER/ MODE	ERROR	PUMP DOWN (L1)	LOW NOISE (L2)	LOW NOISE (L3)	PEAK CUT (L4)	PEAK CUT (L5)	PEAK CUT (L6)
●	○	○	○	○	○	○	○

Sign “○”: Lights off, “●”: Lights on

(3) Press [PUMP DOWN] button for 3 seconds or more after 3 minutes after power on.

POWER/ MODE	ERROR	PUMP DOWN (L1)	LOW NOISE (L2)	LOW NOISE (L3)	PEAK CUT (L4)	PEAK CUT (L5)	PEAK CUT (L6)
●	○	●	○	○	●	●	●

Sign “○”: Lights off, “●”: Lights on

LED display lights on as shown in the above figure, and the fans and the compressor start operating.

- If the [PUMP DOWN] button is pressed while the compressor is operating, the compressor will stop, then start again in about 3 minutes.

(4) LED display will change as shown below about 3 minutes after the compressor starts. Fully close the 3-way valve on the liquid pipe side at this stage.

POWER/ MODE	ERROR	PUMP DOWN (L1)	LOW NOISE (L2)	LOW NOISE (L3)	PEAK CUT (L4)	PEAK CUT (L5)	PEAK CUT (L6)
●	○	●	○	○	○	●	●

Sign “○”: Lights off, “●”: Lights on

- If the valve on the liquid pipe side is not closed, the pump down cannot be performed.

(5) When LED display changes as shown in the below figure, close the 3-way valve on the gas pipe side tightly.

POWER/ MODE	ERROR	PUMP DOWN (L1)	LOW NOISE (L2)	(L3)	PEAK CUT (L4)	(L5)	(L6)
●	○	●	○	○	○	○	●

Sign "○": Lights off, "●": Lights on

- If the valve on the gas pipe side is not closed, refrigerant may flow into the piping after the compressor stops.



(6) LED display changes after 1 minute as shown in the figure below.

POWER/ MODE	ERROR	PUMP DOWN (L1)	LOW NOISE (L2)	(L3)	PEAK CUT (L4)	(L5)	(L6)
●	○	●	○	○	○	○	○

Sign "○": Lights off, "●": Lights on

Fans and compressor stop automatically.

- If the pump down is successfully completed (the above LED display is shown), the outdoor unit remains stopped until the power is turned off.

(7) Turn the power off.

POWER/ MODE	ERROR	PUMP DOWN (L1)	LOW NOISE (L2)	(L3)	PEAK CUT (L4)	(L5)	(L6)
○	○	○	○	○	○	○	○

Sign "○": Lights off

Pump down is completed.

NOTES:

- To stop pump down, press the [PUMP DOWN] button again.
- To start the pump down again after the compressor is automatically stopped due to an error, disconnect the power supply and open the 3-way valves. Wait 3 minutes, reconnect the power supply and start the pump down again.
- When starting the operation after completion of the pump down, disconnect the power supply, and then open the 3-way valves. Wait 3 minutes, reconnect the power supply and perform a test run in the "COOL" operation mode.
- If an error occurs, recover the refrigerant from service port.